

Preparation of Tissue for Scanning Electron Microscopy

1. Fix tissue in 2.5% glutaraldehyde in 0.1M sodium cacodylate buffer pH 7.3 with 3mM CaCl_2 .
2. Rinse 0.1M cacodylate buffer
3. Fix in 1% OsO_4